
Quick User Guide

Accessories

Standard accessories



3 USB ports print server



5V power adapter




Type-c data cable

1 Status Indication




1. Network status
2. Data status
3. Internet connection
4. USB connection
5. Power supply

Interface Description



1. Ethernet interface
2. Expansion storage card slot
3. Power/config interface



4. USB interface-01
5. USB interface-02
6. USB interface-03

2 Config Tool Download

Scan QR code to download device config tool and user manual

Download link: https://loyalty-secutech.com/print-server-data-download/


3 Config Tool Interface (Wired)

Wired Network Config: The print server connects to internet via RJ45 Cable



4 Config Tool Interface (WiFi)

WiFi Network Config: The print server connects to internet via WiFi hotpot



5 Computer Printing (Win/Mac)

Support Print Server config via Windows OS only

Windows98/XP/7/8/10/11



Open config tool to set print server configuration first, add a printer and set a standard TCP/IP port in printer. then explore printing on PC.
Port number: 9100\9101\9102

6 APP Download (Android)



Download the "PrinterShare" or "PrintHand" APP via Google Play

7 Bluetooth Printing


Use device embedded with Bluetooth



Bluetooth Device Info:

Name: Print Server
PIN Code: 0000

8 Workflow



Making Print Sharing Easy and Free!

LOYALTY-SECU Electronics Co.,LTD

LOYALTY -SECU

www.loyalty-secutech.com